





Objectives

- 1. To isolate and troubleshoot to the level of modular components
- 2. To read and comprehend UNICO's system prints and software documentation
 - 3. To understand the function and use of serial communication
 - 4. To understand software and hardware system fault diagnostics
 - 5. To distinguish between normal and abnormal operation
 - 6. To monitor system inputs and outputs to determine the status of the system
 - 7. To locate important system test points for direction to problem areas
 - 8. To understand terminology associated with a drive system

Content Manuals and Drawings

- 1. Understanding how to read and use system prints and manuals
- 2. Using system software documentation to assist in troubleshooting
- 3. Understanding how the application program uses setup data
- 4. Altering setup parameters to assist in troubleshooting
- 5. Understanding the function of DIP switches and jumpers

Physical Identification

- 1. Locating and identifying the controller, amplifier, serial communication devices, and feedback devices
- 2. Identifying modules by name and function within the system
- 3. Identifying modules that occupy dedicated positions within the rack

Servo Theory

- 1. Differentiating between open- and closed-loop systems
- 2. Types of servo-loop systems used by UNICO (hardware vs. software)
- 3. Phasing a servo loop and the results of an improperly phased drive
- 4. Explanation and definition of position loop, velocity loop, and current loop
- 5. Closing the position and velocity loop with more than one feedback device

Communication

- 1. Accessing serial communication and changing setup data using the keyboard
- 2. Monitoring readouts for troubleshooting purposes
- 3. Understanding keystroke commands
- 4. Using different monitors with the system

SYLLABUS

System Training Courses



Content

(continued)

t Feedback Devices

- 1. Understanding pulse generator feedback, including quadrature, single-ended, and differential signals
- 2. Understanding linear absolute encoder feedback, including clock and gate signals
- 3. Understanding resolver feedback, including sine and cosine signals

System Layout

- 1. Understanding how hardware and software function together as a system using block and single-line diagrams
- 2. Identifying the primary function of each module
- 3. Understanding how the system coordinates multiple axes
- 4. Using block diagrams to isolate problems to specific areas

SCR Amplifiers

- 1. Identifying amplifier components, including SCRs, current feedback device, snubber circuit, firing module, Eout, and SCR terminal strip
- 2. Explanation of the function of each terminal board component
- 3. Snubber circuits and why they are needed
- 4. Understanding and observing test points on the SCR terminal strip, including current command, current feedback, current error, and emf
- 5. Symptoms of a shorted or open SCR
- 6. Explanation and illustration of an open-loop test on an amplifier
- 7. Identifying the working components needed to turn on the SCRs

PWM Amplifiers

- 1. Identifying amplifier components, including transistors, current feedback device, heat sink, thermal switch, shunt regulator, and bus discharge circuit
- 2. Understanding basic PWM operation
- 3. Block diagram of DSP operation
- 4. Function and use of the keyboard monitor
- 5. Test points and troubleshooting techniques
- 6. Examining nominal test point charts
- 7. Simulation of common problems and their symptoms
- 8. Interfacing between I/O racks and the amplifier
- 9. Physical identification and review of amplifier terminology
- 10. Troubleshooting hardware using software fault diagnostics

Troubleshooting

- 1. Using hands-on troubleshooting to instill confidence in working with UNICO equipment
- 2. Learning systematic troubleshooting techniques using simulated problems
- 3. Troubleshooting using a functional understanding of the system



Information subject to change without notice.

8405 8/05

UNICO–Worldwide

Corporate Headquarters UNICO, Inc. 3725 Nicholson Road P. O. Box 0505 Franksville, Wisconsin 53126-0505 USA voice: 262.886.5678 fax: 262.504.7396

www.unicous.com

United States Novi, Michigan 248.380.7610 New Lenox, Illinois 815.485.5775 Sandy, Utah 801.501.7586 **Canada** Mississauga, Ontario

905.602.4677

South America El Tigre, Venezuela 58.283.241.4024 Europe Milton Keynes, England 44.1908.260000

44.1908.260000 Wilnsdorf, Germany 49.2739.303.0 **Asia** Osaka, Japan 81.66.945.0077 Beijing, China 86.10.6218.6365